

4 27 GA FLUSH

SHEET

**REVISIONS** 2 OF 4 REV. NO. ZONE: DATE: ECN NO. APPVD: DESCRIPTION 07 SEE REVISION HISTORY ON SHEET ONE.

27 GA LONG MODELS 27 GA SHORT CLOPAY 4300, HDG 4301, HDGF 4310, HDGL HOLMES 66, 66G, 6200 68, 6201 67, 67G, 6203 IDEAL SP200 SF200 SE500


IMPACT-RESISTANT CONSTRUCTION:

SOLID DOORS (NO GLAZING) OR DOORS WITH OPTIONAL IMPACT-RESISTANT GLAZING ARE IMPACT-RESISTANT. OPTIONAL MAX WINDOW SIZE 19-1/2"x12" INJECTION-MOLDED POLYCARBONATE FRONT FRAME AND GLAZING IS GE LEXAN SLX2432T, AN APPROVED CC2 PLASTIC IN ACCORDANCE WITH IBC/FBC 2606 AND AN APPROVED C1 PLASTIC IN ACCORDANCE WITH FBC 2612.

THE ENTIRE DOOR ASSEMBLY INSTALLED IN COMPLIANCE WITH THIS SECTION MEETS THE WIND LOAD REQUIREMENTS OF THE FLORIDA BUILDING CODE AND INTERNATIONAL BUILDING CODE AND IS LARGE- AND SMALL-MISSILE IMPACT RESISTANT.

## SECTION B-B (IMPACT-RESISTANT GLAZING OPTION)

3



MANUFACTURING PRODUCT CODE DSIE-1F171

DESIGN LOADS: +38.0 P.S.F. & -42.0 P.S.F. TEST LOADS: +57.0 P.S.F. & -63.0 P.S.F. Unless Stated Otherwise

TOLERANCES are  $.0 = \pm .031$ 

**C**lopay CORPORATION

8585 Duke Boulevard Mason, OH 45040 USA Tel. No. 513-770-4800 Fax No. 513-770-4853

WINDLOAD RATING

PART NO .: N/A

 $.000 = \pm .005$  $.0000 = \pm .001$ Degrees =  $\pm 1/2$ 

 $.00 = \pm .015$ 

DRAWN BY: SH

DESCRIPTION: 2" EPS INS. DOORS TO 16'2" (SEE TABLE FOR MODELS DATE: 9/28/12 | SCALE: NTS DWG. TO DATE: 10/12/12 SHEET 2 OF 4 SIZE B CHECKED BY: SH Unless Stated Otherwise DIMENSIONS ARE IN INCHES. DWG. NO.: 104724 VER: TDI

DESIGN ENGINEEK:

MARK WESTERFIELD, P.E. FLORIDA P.E. #48495, NC. P.E. #23832, TEXAS P.E. #91513 JONVI

3

2

DESIGN ENGINEER: MARK WESTERFIELD, P.E.

FLORIDA P.E. #48495, NC P.E. #23832, TEXAS P.E. #91513

JAMB CONFIGURATIONS.

DATE: 9/28/12 | SCALE: NTS

Fax No. 513-770-4853

DESCRIPTION: 2" EPS INS. DOORS TO 16'2" (SEE TABLE FOR MODELS

CORPORATION

DRAWN BY: SH

CHECKED BY: SH

 $.0 = \pm .031$  $.00 = \pm .015$ 

Unless Stated Otherwise DIMENSIONS ARE IN INCHES. DWG. NO.: 104724

 $.000 = \pm .005$ 

 $.0000 = \pm .001$ 

Degrees =  $\pm 1/2$ 

 $\triangleright$ 

DATE: 10/12/12 SHEET 3 OF 4 SIZE

VER: TDI

DWG.

