



# Product Evaluation

WIN1381 | 1015

Engineering Services Program

*The following product has been evaluated for compliance with the wind loads specified in the International Residential Code (IRC) and the International Building Code (IBC).*

*This product evaluation is not an endorsement of this product or a recommendation that this product be used. The Texas Department of Insurance has not authorized the use of any information contained in the product evaluation for advertising, or other commercial or promotional purpose.*

*This product evaluation is intended for use by those individuals who are following the design wind load criteria in Chapter 3 of the IRC and Section 1609 of the IBC. The design loads determined for the building or structure shall not exceed the design load rating specified for the products shown in the limitations section of this product evaluation. This product evaluation does not relieve a Texas licensed engineer of his responsibilities as outlined in the Texas Insurance Code, the Texas Administrative Code, and the Texas Engineering Practice Act.*

*For more information, contact TDI Engineering Services Program at (800) 248-6032.*

**Evaluation ID:** WIN-1381

**Effective Date:** October 1, 2015

**Reevaluation Date:** September 2018

**Product Name:** Prime Wood Direct Set Transom Windows, Non-impact Resistant

**Manufacturer:** Lincoln Wood Products, Inc.  
1400 W. Taylor Street  
Merrill, WI 54452  
(715) 536-2461

### General Description:

System	Description	Label Rating	Design Pressure Rating
1	Prime Wood Direct Set Transom Windows; O	TR-R50 111 x 29	+50 / -50 psf

### Product Dimensions:

System	Overall Size	Sash Size
1	110-1/2" x 29"	N/A

### Product Identification (Certification Agency Label on Window):

System		
1	Certification Agency	AAMA
	Manufacturer's Name or Code Name	LN-1
	Product Name	Wood Direct Set Transom
	Test Standards	AAMA/WDMA/CSA 101/I.S.2/A440-05

**Impact Resistance:**

System	Impact Resistant	Requirement
1	No	Provide an impact protective system when installing the product in areas that require windborne debris protection.

**Installation:** Fasten the window to minimum Southern Yellow Pine dimension lumber using the PVC cellular composite brickmould at the head and side jambs of the window frame. Secure the brickmould to the wall framing with minimum No. 8 x 3" PPH screws. Space the fasteners approximately 12" from each corner and approximately 12" on center. Use fasteners long enough to penetrate a minimum of 1-1/2" into the wall framing.

**Note:** Keep the manufacturer's installation instructions on the job site during installation. Use corrosion resistant fasteners as specified in the IRC, IBC, and the Texas Revisions.