

## Product Evaluation

WIN2446 | 0120

Engineering Services Program

The following product has been evaluated for compliance with the wind loads specified in the International Residential Code (IRC) and the International Building Code (IBC).

This product evaluation is not an endorsement of this product or a recommendation that this product be used. The Texas Department of Insurance has not authorized the use of any information contained in the product evaluation for advertising, or other commercial or promotional purpose.

This product evaluation is intended for use by those individuals who are following the design wind load criteria in Chapter 3 of the IRC and Section 1609 of the IBC. The design loads determined for the building or structure shall not exceed the design load rating specified for the products shown in the limitations section of this product evaluation. This product evaluation does not relieve a Texas licensed engineer of his responsibilities as outlined in the Texas Insurance Code, the Texas Administrative Code, and the Texas Engineering Practice Act.

For more information, contact TDI Engineering Services Program at (800) 248-6032.

**Evaluation ID:** WIN-2446

**Effective Date:** January 1, 2020

**Re-evaluation Date:** January 2024

**Product Name:** Heritage Sterling Wood Double Hung Mulled w/ Transom Windows, Non-Impact Resistant

**Manufacturer:** Kolbe & Kolbe Millwork Co.  
1323 South 11<sup>th</sup> Avenue  
Wausau, WI 54401  
(715) 842-5666

### General Description:

System	Description	Label Rating	Design Pressure Rating
1	Heritage Sterling Wood Double Hung Mulled w/ Transom Windows	LC-PG65 (91 x 110.19)-H CW-PG65 (91 x 30)-TR LC-PG65 (46 x 80)-H LC-PG65 Span (91) x TW (55)-MA LC-PG65 Span (80.44) x TW (45.50)-MA	+65 / -65 psf

**Product Dimensions:**

System	Overall Size	Transom Sash Size	Double Hung Window Size
1	91" x 110.19"	91" x 29.50"	Overall: 45.50" x 80.44" Top Sash: 42.19" x 38.25" Bottom Sash: 42.19" x 40.13"

**Product Identification (Certification Label on Window):**

System		
1	Certification Agency	WDMA
	Manufacturer's Name or Code Name	Kolbe & Kolbe Millwork Co., Inc.
	Product Name	Heritage Sterling Double Hung Mull w/ Transom
	Test Standards	AAMA/WDMA/CSA 101/I.S.2/A440-08 AAMA/WDMA/CSA 101/I.S.2/A440-11

**Impact Resistance:**

System	Impact Resistant	Requirement
1	No	Provide an impact protective system when installing the product in areas that require windborne debris protection.

**Installation:****Option #1:**

The wood wall framing members must be minimum Southern Yellow Pine dimension lumber. The window assembly is secured to the wall framing using Kolbe & Kolbe installation clips. Clips must be minimum 10-1/16" long, 1-5/8" wide, and made of 20-gauge galvanized steel. Secure the clips to the window frame using two minimum No. 8 x 3/4" PFH screws and to the wall framing using one minimum No. 8 x 1-3/4" PFH screw. Locate the clips approximately 14-3/4" from each corner along the transom side jambs and 22-3/4" from each corner and on center along the head of the transom. For the double hung windows, locate clips approximately 13-13/32" from each corner and on center along the side jambs. Fasteners must be long enough to penetrate a minimum of 1-1/2" into the wall framing members.

**Option #2:**

The wood wall framing members must be minimum Southern Yellow Pine dimension lumber. The window assembly is secured to the wall framing using minimum No. 10 x 2-1/2" PFH screws spaced approximately 14.75" from each corner along the transom side jambs, 15.17" from the corner and on center at the head, and 13.41" from each corner and on center along the double hung window side jambs. Fasteners must be long enough to penetrate a minimum of 1-1/2" into the wall framing members.

**Note:** Keep the manufacturer's installation instructions available on the job site during installation. Use corrosion resistant fasteners as specified in the IRC and the IBC.