



# Product Evaluation

DR693 | 1014

Engineering Services Program

*The following product has been evaluated for compliance with the wind loads specified in the International Residential Code (IRC) and the International Building Code (IBC).*

*This product evaluation is not an endorsement of this product or a recommendation that this product be used. The Texas Department of Insurance has not authorized the use of any information contained in the product evaluation for advertising, or other commercial or promotional purpose.*

*This product evaluation is intended for use by those individuals who are following the design wind load criteria in Chapter 3 of the IRC and Section 1609 of the IBC. The design loads determined for the building or structure shall not exceed the design load rating specified for the products shown in the limitations section of this product evaluation. This product evaluation does not relieve a Texas licensed engineer of his responsibilities as outlined in the Texas Insurance Code, the Texas Administrative Code, and the Texas Engineering Practice Act.*

*For more information, contact TDI Engineering Services Program at (800) 248-6032.*

**Evaluation ID:** DR-693

**Effective Date:** September 1, 2014

**Revised:** October 1, 2014

**Re-evaluation Date:** April 2017

**Product Name:** Ultra Aluminum Clad Wood Glazed Inswing Hinged Entry Door, Non-impact Resistant

**Manufacturer:** Kolbe & Kolbe Millwork Co., Inc.  
1323 South Eleventh Avenue  
Wausau, WI 54401  
(715) 842-5666

### General Description:

System	Description	Label Rating	Design Pressure Rating	Hallmark Certification
1	Ultra Aluminum Clad Wood Inswing Hinged Entry Door	LC-PG50 38x99 – SHD	+50/-50	413-H-1258.00 413-H-1258.01

### Component Dimensions:

System	Overall Size	Panel Size	Panel Daylight Opening Size
1	37.63" x 98.72"	35.81" x 95.97"	27" x 84"

### Hardware:

- **5-point Lock with Three Strikes on Side Jamb and Shoot Bolts Strikes at Head and Sill:** one required; locate on the panel
- **Dead Bolt Lock (Hoppe HLS9000):** locate on the panel
- **Dead Bolt/Latch Strike Plate:** One required on door side jamb; secure with three (3), No. 7 x 5/8" screws
- **Strike Plates:** one required at head and one at sill, both on side jamb; secure each with two (2), No. 7 x 5/8" screws.

- **Shoot Bolt Strike Plates:** One required at the head and one at the sill; secure the head strike plate with two (2), No. 9 x 2" screws and the sill strike plate with two (2), No. 8 x 1" screws.
- **Hinges:** Four on each panel; secure each to the door panel with four (4), No. 9 x 2" screws and to the side jamb with three (3), No. 9 x 3/4" screws and one (1), No. 10 x 2-1/2" screw.

**Product Identification (Certification Agency Label on Door):**

System		
1	Certification Agency	WDMA
	Manufacturer's Name or Code Name	Kolbe & Kolbe Millwork Co., Inc.
	Product Name	Ultra Inswing Door
	Test Standards	AAMA/WDMA/CSA 101/I.S.2/A440-08

**Impact Resistance:**

System	Impact Resistant	Requirement
1	No	Install an impact protective system when installing the product in areas that require windborne debris protection.

**Installation:**

**Option 1 (Installation Clips):** Fasten door assembly to minimum Southern Yellow Pine lumber. Secure door assembly to wall framing using Kolbe & Kolbe metal installation clips. Secure installation clips (1-5/8" x 10-1/16" x 0.04") to doorframe side jambs, head, and sill. Secure clips to the doorframe with two (2), No. 8 x 3/4" screws, and to the wall framing with one (1), No. 8 x 1-3/4" screw. Use fasteners long enough to penetrate a minimum of 1-1/2" into the framing. The table below specifies the spacing of the clips.

System	Distance From Each Corner	Head (on center spacing)	Sill (on center spacing)	Side Jambs (on center spacing)
1	Head: 18-13/16" Side Jambs: 19-3/4"	N/A	See Below	Door: 19-3/4"

**Sill:** Secure sill to wall framing with minimum No. 10 x 2-1/2" screws. Locate fasteners approximately 5" and 19-11/16" from each door corner. Fasteners must be long enough to penetrate a minimum of 1-1/2" into the framing.

- **Option 2 (Screws through Frame):** Fasten door assembly to minimum Southern Yellow Pine lumber. Secure door assembly to the wall framing using the doorframe with minimum No. 10 x 2-1/2" screws. Use fasteners long enough to penetrate a minimum of 1-1/2" into the framing. The table below specifies the spacing of the fasteners.

System	Distance From Each Corner	Head (on center spacing)	Sill (on center spacing)	Side Jambs (on center spacing)
1	Head: 5" and 18-11/16" Door Side Jambs: 19-3/4"	N/A	See Below	19-3/4"

**Sill:** Secure sill is to wall framing with minimum No. 10 x 2-1/2" screws. Locate fasteners approximately 5" and 19-11/16" from each corner. Use fasteners long enough to penetrate a minimum of 1-1/2" into the wall framing.

- **Nailing Fin (Options 1 and 2):** Secure nailing fin to wall framing with minimum 11-gauge smooth shank roofing nails spaced approximately 7" on center along the head and side jambs.

**Note:** The manufacturer's installation instructions must be available on the job site during installation. All fasteners must be corrosion resistant as specified in the IRC, the IBC, and the Texas Revisions.